



---

# ILUM2440

DHCP on Linux

## Enabling on Linux

After login, on terminal, run the following command:

```
" mv /etc/init.d/s40network /etc/init.d/S40network "
```

Restart the board. Now the DHCP client will work only on board startups otherwise you should run following command to renew IP address:

```
" /etc/init.d/S40network restart "
```

## Disabling on Linux

After login on terminal, run the following command:

```
" mv /etc/init.d/S40network /etc/init.d/s40network "
```

Restart the board. Now the DHCP client will not work and the default IP address is 192.168.2.2